

**LED status indicator**

The LED status indicator on the Wattpilot indicates whether the system is switched on and the current system status of the Wattpilot. One LED represents one ampere (1 A). A maximum of 32 A is displayed. The first two LEDs indicate the currently active operating mode. If these do not light up white, the Wattpilot is in standard mode - charging takes place with the maximum set current without taking surplus PV electricity and flexible electricity tariffs into account.



**Eco Mode**

The Wattpilot is in Eco Mode.


- The first LED lights up white.
- The first LED flashes orange (see chapter [Status Codes](#) on page 67).
- The first LED flashes red (see chapter [Status Codes](#) on page 67).



**Next Trip Mode**

The Wattpilot is in Next Trip Mode.


- The second LED lights up white.
- The second LED flashes orange (see chapter [Status Codes](#) on page 67).
- The second LED flashes red (see chapter [Status Codes](#) on page 67).



**Starting**

The Wattpilot is starting up or restarting.



- The LEDs light up in rainbow colours.



**Ready**

The Wattpilot is ready for operation. The number of LEDs that light up indicates the set charging current. Each LED represents 1 ampere (A). A maximum of 32 A can be displayed, whereby the first two LEDs are reserved for the charging modes.


- A few blue LEDs light up = low charging current (e.g. 10 LEDs = 10 A).
- Several/all blue LEDs light up = high charging current (e.g. 32 LEDs = 32 A).



**Enable**

The Wattpilot must be activated via the app or an ID chip.


- The LEDs light up blue, four pairs of LEDs run in a quarter circle from the top and bottom towards each other.



### Waiting

The Wattlepilot is waiting for cheap electricity from a photovoltaic system or electricity provider, or the charging timer is active.



- The LEDs flash blue in the number of amperes set.



### Wait for car

The Wattlepilot recognises the connected vehicle and the set charging parameters. Charging has been enabled by the charging station but not yet started by the car.



- A few yellow LEDs light up when the charging current is low.
- Several/all yellow LEDs light up when the charging current is high.



### 1-phase charging

The Wattlepilot is carrying out 1-phase (230 V) charging with low to high charging current.


- One series of blue LEDs moves in a clockwise direction.
- The level of charging current is indicated by the number of LEDs and the speed of rotation.




### 3-phase charging

The Wattlepilot is carrying out 3-phase (400 V) charging with low to high charging current.

- Three series of blue LEDs move in a clockwise direction.






#### Charging finished

The charging process is complete.


- All LEDs light up green.



#### ID chip detected

The Wattpilot has detected an authorised ID chip.


- Five LEDs light up green.



#### Invalid value

Wattpilot displays an invalid input. Pressing the pushbutton was not permitted or an ID chip was detected but not authorised.


- Five LEDs light up red.



#### Earthing test deactivated

The earthing test is deactivated.


- Four LEDs light up at 3, 6, 9 and 12 o'clock.



#### Internal communication fault

The Wattpilot displays an internal communication error. The error code is displayed in the app. For more information, see [Status Codes](#) on page 67.


- All LEDs flash red.



#### Residual current detected

The Wattpilot has detected a residual current ( $\geq 6 \text{ mA}_{\text{DC}}$  or  $\geq 20 \text{ mA}_{\text{AC}}$ ). Restart the Wattpilot. For more information, see [Status Codes](#) on page 67.


- The LEDs light up pink, the LEDs at the top flash red.



#### Earth fault detected


The earthing of the supply line to the Wattpilot is faulty. Check the earthing of the supply line. For more information, see [Status Codes](#) on page 67.

- The LEDs light up green and yellow, the LEDs at the top flash red.




**At least one phase of the power supply is missing**  
The phase(s) of the supply line to the Wattpilot has/have failed. Check the phase(s) of the supply line. For more information, see [Status Codes](#) on page 67.

- The LEDs light up blue, the LEDs at the top flash red.




**Temperature too high**  
The temperature of the Wattpilot is too high. The charging current is reduced. For more information, see [Status Codes](#) on page 67.

- The LEDs light up yellow, the LEDs at the top flash red.




**Unlocking or locking error**  
Unlocking or locking has failed. The unlocking or locking attempt is repeated at 5-second intervals. For more information, see [Status Codes](#) on page 67.

- The LEDs light up red at the top and yellow at the bottom for 1 second.




**Charge controller error**  
The charge controller is not working properly. For more information, see [Status Codes](#) on page 67.

- The LEDs light up red at the top and yellow at the bottom for 1 second.




**Update**  
The Wattpilot firmware is being updated. The update can take several minutes. Do not unplug the charging station.

- All LEDs flash pink, the progress of the update is indicated by yellow LEDs.




**Update successful**

- The LEDs light up alternately pink and green.



**Update failed**

- The LEDs light up alternately pink and red.
-



### **Reset card detected**

The Wattpilot has detected the reset card and the settings are reset.

- All LEDs light up red for 2 seconds.
-